








AUSTAUSCHFEDERN für das Originalfederbein REPLACEMENT SPRINGS for OEM shock absorber

		 2 April			€	 Deutsch	 English
HONDA							
NTV 650 Revere	RC 33	88-91		496-010-00	89,-		
XRV 750 Africa Twin	RD 07	93>		496-059-00	89,-		
XL 1000 Varadero	SD 01/SD 02/ 4 XM	99-03		496-008-01	89,-		
KAWASAKI							
KLX 650 R	LX 650 A	93>		496-025-00	89,-		
ZX 9 R Ninja	ZX 900 B	94-97		496-028-00	89,-		
ZX 10 R	ZXT00C	04>		496-069-00	89,- + Kit	Nur mir Kit	Only with kit
SUZUKI							
DRZ 400 Cup-Supermoto	WVB8	05>		496-070-00	89,-	60 N/mm	60 N/mm
DRZ 400 Cup-Supermoto	WVB8	05>		496-071-00	89,-	65 N/mm	65 N/mm
DL 650 V-Strom	WVB1	04>		496-006-01	89,-		
SV 650	WVBY	03>		496-004-00	89,-		
GSX-R 1000 (87 N/mm)	WVBL / BZ	01-06		496-007-00	89,-	90 N/mm	90 N/mm
GSX-R 1000 (95 N/mm)	WVBL / BZ	01-06		496-005-01	89,-	95 N/mm	95 N/mm
DL 1000 V-Strom	WVBS	02>		496-006-01	89,-		
SV 1000	WVBX	03>		496-004-01	89,-		
YAMAHA							
YZF 600 R 6	RJ 03	98>		496-009-01	89,-		